

Seat (generic) : 99
 Seat belts: 157-158
 Seating: 166 – 168
 Seat: 199 - 212
 SRS AirBag: 230 - 232

Driver (RHD) → Passanger (LHD). C33A <=> C33B

1	BAT → Junction Box Central Yellow – Red (YE-RD), 2.5, Seat motors Page: 206, 207
4	Lumb Pomp Violet Grey (VT-GY), 0.5, Lumb Pomp page: 206, 207
6	Sensor-Seat Position Driver Blue – Grey (BU-GY), 0.35, Seat Belt / Sensor- Seat Position Driver page: 232
7	Sensor-Seat Position Driver Grey – Violet (GY-VT), 0.35, Seat Belt / Sensor- Seat Position Driver page: 232
8	Restraints Control Module (RCM) Blue – orange (BU-OG), 0.35, Seat Belt page: 232
9	Restraints Control Module (RCM) Blue – Grey (BU-GY), 0.35, Seat Belt page: 232
10	Side AirBag RHS+ (LHS / LHD) Green - Blue (GN-BU), 0.35, SRS AirBag page: 230
11	Side AirBag RHS- (LHS / LHD) Grey – Yellow (GY-YE), 0.35, SRS AirBag page: 230
12	LIN B RIGHT Brown violet (BN-VT), 0.35, Heating page: 204, 205
13	Power from Ignition → Junction Box Rear Yellow (YE), 1.5, Heating page: 204, 205
21	GND1 Black – Yellow (BK-YE), 2.5, ground
24	GND2 Black – Yellow (BK-YE), 1.5, ground

	page: 207
--	-----------

Passanger (RHD) → Driver (LHD). C33C <=> C33D

1	BAT → Junction Box Central Grey – Red (GY-RD), 2.5, Seat motors Page: 206
4	Sensor Occupant detection Black Green (BK-GN), 0.35, SRS Airbag page: 157
5	Side AirBag LHS+ (RHS / RHD) Violet – Grey (VT-GY), 0.35, SRS AirBag page: 230
6	Side AirBag LHS- (RHS / RHD) Yellow – Orange (YE-OG), 0.35, SRS AirBag page: 230
11	Restraints Control Module (RCM) Blue – Grey (BU-GY), 0.35, Seat Belt page: 232
12	Restraints Control Module (RCM) Grey – Violet (GY-VT), 0.35, Seat Belt page: 232
13	PWR GND 2 Black (BK), 2.5, ground
15	Sensor Occupant detection Brown Yellow (BN-YE), 0.35, SRS Airbag page: 157
17	LIN A LEFT White Green (WH-GN), 0.35, Heating page: 204, 205
20	Lumb Pomp Violet Grey (VT-GY), 0.5, Lumb Pomp page: 166, 206
21	GND 1 Black(BK), 1.5, ground page: 206
24	Power from Ignition → Junction box - Read Red (ED), 1.5, Heating page: 204, 205